






G M 5022

Tools for Installation



A

A1 X1	A2 X1	A3 X20	A4 X1	A5 X1	A6 X1	A7 X2	A8 X8
A9 X3	A10 X15	A11 X5	A12 X3	A13 X10	A14 X1	A15 X1	A16 X5

B

B1 X2	B2 X2	B3 X8	B4 X2	B5 X4	B6 X20	B7 X2	B8-A X2
B8-B X2	B9 X2	B10 X4	B11 X4	B12 X2	B13-A X4	B14 X2	B15 X4
B17 X6	B18 X8	B19 X6					

